

INSTRUCTION MANUAL FOR MIYOTA WATCH MOVEMENT

CALIBER NO. 6P28

BATTERY: SR621SW

FEATURES : ANALOG MULTI-FUNCTION QUARTZ WATCH WITH
24HOUR


INSTRUCTION MANUAL

A) DISPLAY

B) OPERATION PROCEDURE

C) SETTING THE TIME (HOUR, 24 HOUR, MINUTE AND SECOND)

A) DISPLAY



NORMAL CROWN POSITION

1ST POSITION

TIME SETTING (CLOCKWISE)

B) OPERATION PROCEDURE

1 SETTING THE TIME (HOUR, 24HOUR, MINUTE and SECOND)

C) SETTING THE TIME (HOUR, 24 HOUR, MINUTE AND SECOND)

The hour, 24 hour, minute and second are set by the same operation.

SETTING PROCEDURE

HOUR&24HOUR → MINUTE → SECOND

Pull the crown out to the 1st position to stop the second hand at 0 (12 o'clock).

Turn the hour/minute hands in a **clockwise** direction to set the time.

To ensure time is set accurately, first turn the minute hand 5 minutes ahead of desired time and then turn back (in a counterclockwise) to the desired time.

After setting the time, use a time signal to synchronize the watch by pushing crown to the normal position to start the second hand going.

NOTE:

Make sure you have correctly set AM/PM before setting the time.